

# Health Monitoring Report

## RIKEN BioResource Center

RIKEN BioResource Center adopts the sentinel mouse program, which is specialized for the micro isolator cage system. A sentinel mouse cage containing four mice is laid on a microisolator cage rack and small parts of dirty beddings from all cages of the rack are collected into the sentinel mouse cage every two weeks. One mouse from a sentinel cage is subjected to the examination bimonthly for our examination.

Our items to be examined are classified into four classes shown in the table below. All sentinel mice are tested under the class A and B. Sentinel mice kept in the room for immuno-deficient mice are screened on the class C as well. The class D contains a weak pathogen (MNV) or the certain pathogens that are believed not to exist in the Japanese mouse colonies hence mice are submitted to class D examination by request at recipient's charge.

Top of row of health report indicates the index code of the sentinel animals tested. First two letters mean the room number, and the last letter means the rack code.

For example;

If the index code is 3-1-A, the sentinel mouse tested is from the room "3-1" rack "A".

Class	Microorganisms
A	<i>C.piliforme</i> , Ectromelia virus, Hantaan virus, Lymphocytic choriomeningitis virus (LCMV), Mouse hepatitis virus (MHV), <i>M.pulmonis</i> , Sendai virus (HVJ)
B	<i>C.rodentium</i> , <i>C.kutscheri</i> , <i>F.rodentium</i> ('CAR bacillus') <i>P.pneumotropica</i> , <i>Salmonella</i> spp., <i>H.bilis</i> , <i>H.hepaticus</i> , Dermatophytes, Ectoparasites, Intestinal protozoa, Pinworms
C	<i>S.aureus</i> , <i>P.aeruginosa</i> , <i>P.murria</i>
D	Pneumonia virus of mice (PVM), Theiler's mouse encephalomyelitis virus (TMEV/GDVII), Mouse minute virus (MMV), Mouse parvovirus (MPV), Mouse polyoma virus (Poly), Reovirus type 3 (Reo3), Mouse adenovirus (MAV), Mouse rotavirus (EDIM), Mouse cytomegalovirus (MCMV), Lactate dehydrogenase elevating virus (LDHEV), Mouse norovirus (MNV)

Fumio Ike, Ph.D.  
Experimental Animal Division  
RIKEN BioResource Center  
3-1-1 Koyadai, Tsukuba, Ibaraki 305-0074 JAPAN  
Phone: :81-298-5264  
FAX: +81-298-36-9010  
E-Mail: [ike@brc.riken.go.jp](mailto:ike@brc.riken.go.jp)

# HEALTH REPORT

1/2

Facility: RIKEN BRC Experimental Animal Division

Testdate: December 4, 2017

Examination No: 17593

Class	Pathogen(s)	Method(s)	Sentinel Animal(s) : BALB/cA-nu/+ ♀									
			3-2-A	3-2-B	3-2-C	3-2-D	3-3-A	3-3-B	3-3-C	3-3-D	3-5-A	3-5-B
A	Mouse hepatitis virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Sendai virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Clostridium piliforme</i>	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Hantaan virus	Serology										
	Ectromelia virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Lymphocytic choriomeningitis virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Mycoplasma pulmonis</i>	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
Cultivation		0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	
A/B	<i>Salmonella</i> spp.	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
B	<i>Citrobacter rodentium</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Corynebacterium kutscheri</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Pasteurella pneumotropica</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Dermatophytes	Cultivation										
	<i>Filobacterium rodentium</i> *	Serology	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Ectoparasites	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Intestinal protozoa	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Pinworms	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Helicobacter bilis</i>	PCR	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	<i>Helicobacter hepaticus</i>	PCR	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
C	<i>Pseudomonas aeruginosa</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Gross lesion		0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

\* Formerly known as "CAR bacillus"

**RIKEN BioResource Center**  
 Experimental Animal Division  
 3-1-1 Koyadai, Tsukuba, Ibaraki, 305-0074, JAPAN  
 Phone: +81-29-836-5264 FAX: +81-29-836-9010



Fumio Ike, Ph.D.

# HEALTH REPORT

2/2

Facility: RIKEN BRC Experimental Animal Division

Testdate: December 4, 2017

Examination No: 17593

Class	Pathogen(s)	Method(s)	Sentinel Animal(s) : BALB/cA-nu/+ ♀								
			3-5-C	3-5-D	3-6-A	3-6-B	3-6-C	3-6-D			
A	Mouse hepatitis virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	Sendai virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Clostridium piliforme</i>	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	Hantaan virus	Serology									
	Ectromelia virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	Lymphocytic choriomeningitis virus	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Mycoplasma pulmonis</i>	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
Cultivation		0/1	0/1	0/1	0/1	0/1	0/1				
A/B	<i>Salmonella</i> spp.	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1			
B	<i>Citrobacter rodentium</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Corynebacterium kutscheri</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Pasteurella pneumotropica</i>	Cultivation	0/1**	0/1**	0/1	0/1	0/1	0/1			
	Dermatophytes	Cultivation									
	<i>Filobacterium rodentium</i> *	Serology	0/1	0/1	0/1	0/1	0/1	0/1			
	Ectoparasites	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1			
	Intestinal protozoa	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1			
	Pinworms	Microscopy	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Helicobacter bilis</i>	PCR	0/1	0/1	0/1	0/1	0/1	0/1			
	<i>Helicobacter hepaticus</i>	PCR	0/1	0/1	0/1	0/1	0/1	0/1			
C	<i>Pseudomonas aeruginosa</i>	Cultivation	0/1	0/1	0/1	0/1	0/1	0/1			
	Gross lesion		0/1	0/1	0/1	0/1	0/1	0/1			

\* Formerly known as "CAR bacillus"

\*\* Strains positive for *P. pneumotropica* were found at 3-5-C, 3-5-D by fecal PCR and direct swab culture tests during the sentinel test interval. Please inquire for details at animal@brc.riken.jp

**RIKEN BioResource Center**  
 Experimental Animal Division  
 3-1-1 Koyadai, Tsukuba, Ibaraki, 305-0074, JAPAN  
 Phone: +81-29-836-5264 FAX: +81-29-836-9010



Fumio Ike, Ph.D.